# iBiking+

# User Manual

Download on the App Store

ANDROID APP ON Google play

## CONTENT


Android Cell Phone Bluetooth setting instruction 01

iOS Cell Phone Bluetooth setting instruction 03

Log in setting instruction 04

Target setting instruction 09

Quick Start setting instruction 11

HRC setting instruction 12

iRoute setting instruction 14

Workout summary 18

# Android Cell Phone Bluetooth setting instruction

1




Download iBiking+ in Google play system requirements:
480*800, 720*1280, 1280*800
Android 2.2 or above.
Support Android devices:
Samsung Galaxy Note 1~4
Samsung Galaxy S2~5
HTC NEW ONE
HTC D316d
HTC M8
SONY Z ULTRA

2




After finish download,
open the APP and click bottom left triangle icon for Bluetooth paring.

3




Press "SCAN FOR DEVICES", check on the device and enter the default code: 0000.

4




Entering the APP.

## iOS Cell Phone Bluetooth setting instruction

1




Download iBiking+ in APP STORE, system requirements: iOS 5.1.1 or above.
Support iOS devices: iPhone4s,iPhone5,iPhone5s,iPhone6

2




After finish download, turn on the tablet's Bluetooth, and start searching the device.

3

Check on the device and enter the default code: 0000.

4




Entering the APP.



## Log in setting instruction

1




"SETTING"
Edit Profile.

2

Select Imperial / Metric.

3

Gear Ratio is setting by the factory therefore, the value adjustment is depending.
(For example, if bike's ratio is 1: 3, then the Gear Ratio value needs to adjust to 3)

4

User can adjust gear ratio value, and X is for clear.

5

First time using this app,
user needs to log in.
Press “LOG IN”.

6

Log in by user's Google/FB
account or create a new account.

9

Loading.

10

Log in success.

7




Log in with Google account.

8




Pressing “ACCEPT”.

11

Log in with Facebook account.

12

Loading.

13

Log in success.

14




Create a new account.

17




Find the account activating mail and click the URL to verify the account.

18




After log in press “EDIT” to create personal data.

15

Key in user's account info and password.

16




Enable the email account.

19

Fill in personal data.

20

Click camera icon to choose picture or take picture. Then press “DONE” to finish setting.

# Target setting instruction

1




“TARGET”.

2

Setting “TIME”.

3

Setting “DISTANCE”.

4

Setting “CALORIES”.

5

The setting “TIME” starts countdown.
User can press pause from console control to stop exercise any time.
The display values would be different depending on the change of treadmill.

6




When finish, the workout summary can post on Facebook or Twitter.

7




Click Facebook to upload the workout summary.

## Quick Start setting instruction

1




"QUICK START"

2

After starting exercise user can press pause from console control to stop any time.
The display values would be different depending on the change of treadmill.

3

When finish, the workout summary can post on Facebook or Twitter.

4

Click Facebook to upload the workout summary.



## HRC setting instruction

1




In "HRC" section must have i-Pulse Dongle for receiving heart rate signal.

2

User can custom the percentage.

3

Setting "TIME"

4

The setting TIME starts countdown.

5

As over the target heart value, there would be a warning.

6

When finish the workout summary can post on Facebook or Twitter.

7




Click Facebook to upload the workout summary.

## iRoute setting instruction

1




Press “PURCHASED ITEMS” to entry.

2

Press “iRoute” to entry.

3

Press “PLAN MY OWN ROUTE”.

4

Input the key word to search location.

5




Or user can set a start point and end point by own as holding press for two seconds, which can select a total of eight turning points between.

6

Press ”MY FAVORITES”

9




Standard Mode.

10




Hybrid Mode.

7

There are five default routes n my favorites.
User selected route can save in my favorites.

8




After finish setting route and start exercise, there are three vision modes can choose.

11

Street view Mode.

12




When finish the workout summary can post on Facebook or Twitter.

13

Click Facebook to upload the workout summary.

14




After finish workout, user can save the route to my favorites section by press the Star icon which is next to the home icon.

15

User can named the route. Press “SAVE” to store.

16




The saving route will show on my favorites section.



## Workout summary

1

Click “iBiking +”

2

All the workout histories show up. The trash can icon can delete and in the calendar icon lists the dates that user had been workout.

3

In delete function, user can click on the white box for each or press “ALL” to select all.

4

After selecting, press the trash can icon in middle, then the workout history can be delete. Press X to cancel.

5




In the calendar section lists the dates that user had been workout which would mark in red dot.
Grey dot represents the month.